


OPEN AND ENCLOSED GA SERIES 16A TO 160A SWITCH DISCONNECTORS

Three-pole disconnectors

GA016...GA160A/C
GAZ016...GAZ160/B
GAZ016UL...GAZ125UL



Fourth pole

GAX42...




GAX41...



Four-pole disconnectors


GAZ016 T4...GAZ160 T4
GAZ016 T4UL...GAZ125 T4UL



ADD-ON BLOCKS AND ACCESSORIES

Auxiliary contacts

GAX10...



GAX11... - GAX12...



Neutral terminal

GAX31... - GAX32...




Earth/Ground terminal

GAX33... - GAX34...




Fuse holder

GAX39 1




ENCLOSED CHANGEOVER SWITCHES

Three-pole **GAZ...ET6**




Four-pole **GAZ...ET8**



GE SERIES - 50A TO 1600A SWITCH DISCONNECTORS


Three-pole disconnectors

GE0160 - GE1600
GE0160 P




Three-pole disconnectors with fuse holders

GE0050 F - GE0125 F
GE0160 N - GE0800 N
GE0160 B - GE0800 B




Four-pole disconnectors

GE0160 T4 - GE1600 T4
GE0160 T4P



Four-pole disconnectors with fuse holders


GE0050 FT4 - GE0125 FT4
GE0160 NT4 - GE0800 NT4
GE0160 BT4 - GE0800 BT4




160A TO 1250A CHANGEOVER SWITCHES

Three-pole switches

GE0160 E - GE0200 E




GE0201 E - GE1600 E




Four-pole switches

GE0160 ET4 - GE0200 ET4



GE0201 ET4 - GE1600 ET4



ADD-ON BLOCKS AND ACCESSORIES


Auxiliary contacts

GEX10 11 - GEX10 11M - GEX10 11N




Motorised control unit

GEX69 0C - GEX69 1C



Motorised control unit


GEX69 2 - GEX69 3




SWITCH DISCONNECTORS FOR PHOTOVOLTAIC APPLICATIONS **GA...D** (poles in series to wire)

One-line control


2 poles in series



3 poles in series




4 poles in series



Two-lines control

2+2 poles in series




① The positive pole fitted on the right side of the disconnector can also be fitted on the left side; the connections must be changed in consequence.


SWITCH DISCONNECTORS FOR PHOTOVOLTAIC APPLICATIONS **GD...** (jumpers supplied as standard)

One-line control


GD025 AT2



GD032 AT3




GD040 AT4



SWITCH DISCONNECTORS FOR PHOTOVOLTAIC APPLICATIONS **GE...DT4** (poles in series to wire)

One-line control

4 poles in series



4 (2+2) poles in series

